



Mounting Template.

Positioning the front hole of the binding at the center of ski!
Use drill diam. 4.1 only, depth of hole min. 9 mm.

Important:

Check the scale of the hole distance
after printing this page!
(Printer zoom factor 100%)

